
# SERVICE PARTS LIST

BULLETIN NO.
**54-05-0100**

| SPECIFY CATALOG NO. AND SERIAL NO. WHEN ORDERING PARTS | | | | REVISED BULLETIN | DATE |
|---|---|---|---|---|---|
| **M18™ COMPACT VACUUM** | | | | | Oct. 2017 |
| **CATALOG NO.** | **0882-20** | STARTING SERIAL NO. | **H64A** | WIRING INSTRUCTION | |

**EXAMPLE:**
00 — 0
Component Parts (Small #) Are Included When Ordering The Assembly (Large #).




| FIG. | PART NO. | DESCRIPTION OF PART | NO. REQ. |
|---|---|---|---|
| 1 | 05-88-0006 | M3 x 16 Screw | (21) |
| 2 | 14-38-0409 | Top Cover | (1) |
| 3 | 31-50-0891 | Motor Inner Housing | (1) |
| 4 | 14-30-2435 | Motor Assembly | (1) |
| 5 | 42-14-0026 | Deflector | (1) |
| 6 | 49-90-0160 | Filter | (1) |
| | 49-90-1951 | Filter (2-Pack) | (1) |
| 7 | 42-51-0386 | Canister | (1) |
| 8 | 14-38-0536 | Housing Assembly | (1) |
| 9 | ---------- | Right Housing | (1) |
| 10 | 31-15-0023 | Canister Lid Assembly | (1) |
| 11 | 45-76-0260 | Inlet | (1) |
| 12 | 05-88-0007 | M3 x 10 Screw | (5) |
| 13 | ---------- | Left Housing w/ Pin | (1) |
| 14 | 44-66-0864 | Press Plate | (1) |
| 16 | 23-66-0038 | Switch Lock-On Button | (1) |

| FIG. | PART NO. | DESCRIPTION OF PART | NO. REQ. |
|---|---|---|---|
| 17 | 40-50-0231 | Spring | (1) |
| 18 | 06-81-0401 | Washer Head Screw | (1) |
| 19 | 14-20-0109 | Electronics Assembly (wires not shown) | (1) |
| 20 | ---------- | PCBA | (1) |
| 21 | ---------- | Battery Terminal Connector Block | (1) |
| 22 | ---------- | On/Off Switch | (1) |
| 23 | 23-66-0056 | Trigger Assembly | (1) |
| 24 | ---------- | Trigger Holder | (1) |
| 25 | ---------- | Trigger Spring | (1) |
| 26 | ---------- | Trigger | (1) |
| 27 | 31-01-0865 | Crevice Tool | (1) |
| 28 | 31-01-0860 | Floor Tool | (1) |
| 29 | 14-37-0170 | Hose | (1) |
| 30 | 45-76-0990 | Extension Tube | (1) |
| 31 | 12-20-0097 | Service Nameplate (not shown) | (1) |


**MILWAUKEE TOOL • www.milwaukeetool.com**
13135 W. LISBON RD., BROOKFIELD, WI 53005

Drwg. 3