95G1UH110CE20				DASH/Revision # with Qty					
Key	Part Name	Part Number	Description	1	2	3	5	6	55
Category:									
9080	604888-03 ASSY KIT (NAT TO PROPANE CONV)	68W75	604888-03 ASSY KIT (NAT TO PRO PANE CONV)	1	1	1	1	1	1
90	LB-29333BCW WHEEL-BLOWER	36M22	LB-29333BCW WHEEL	1	1	1	1	1	1
820	102862-01 Coupling -2"	72W54	102862-01 Coupling-2"	1	1	1	1	1	
820	102862-02 Flue Cou pling Service Kit	14K09	102862-02 Flue Coupling Servic e Kit						1
721	102809-01 Hose Dra in (UH)	71W35	102809-01 Hose Drain (UH)	1	1				
721	102809-02 Hose Dra in (UH)	71W36	102809-02 Hose Drain (UH)	1	1	1	1	1	1
721	102809-03 Hose Dra in	98W72	102809-03 Hose Drain			1	1	1	1
700	614169-01 AIR INLE T GASKET ASSY	71W27	102510-01 Collar-Air Inlet	1	1	1	1	1	1
70	100071-03 SLEEVE	42W05	100071-03 Sleeve	4	4	4	4	4	4
70	43H8101 GROMMET	43H81	GROMMET	4	4	4	4	4	4
70	607421-11 X13 1HP Motor - Programmed	81W42	607421-11 X13 1HP Motor - Pro grammed	1	1	1	1	1	1
70	ARM-MOTOR MTG	49L97	ARM-MOTOR MTG	4	4	4	4	4	4
70	MOUNT-MOTOR	32M17	MOUNT-MOTOR	1	1	1	1	1	1
60	102907-01 Roll Out Switch (210F)	71W49	102907-01 Roll Out Switch (210 F)	2	2	2	2	2	2
53	104007-01 TRANSFOR MER POWER CHOKE	10Y66	104007-01 TRANSFORMER POWER CH OKE						1
53	42J3201 TRANSFORME R	42J32	42J3201 TRANSFORMER	1	1	1	1	1	1
53	69H1201 POWER CHOK E	69H12	POWER CHOKE	1	1	1	1		
500	102788-17 Box-Coll ector	77W17	102788-17 Box-Collector	1					
500	102788-31 Box-Coll ector (See text)	86W22	102788-31 Box-Collector		1				
500	610261-12 Box-Coll ector (103370-15)	95W96	610261-15 Box-Collector			1	1		1
500	610261-37 BOX-COLL ECTOR (103370-53)	13H42	610261-37 Cold End Header Box Kit					1	
500	610261-43 BOX-COLL ECTOR (103370-69)	13U37	610261-43 BOX-COLLECTOR (10337 0-69)						
50	LB-94724AE Assy-Bl ower (Replacemt-Comb)	93W13	LB-94724AE Assy-Blower (Replac emt-Comb)			1	1	1	1
50	LB-94724Y Blower-C omb Air S/A	73W44	LB-94724Y Blower-Comb Air S/A	1	1				

95G1UH110CE20				DASH/Revision # with Qty					
Key	Part Name	Part Number	Description	1	2	3	5	6	55
40	102837-01 VALVE-GAS (NAT)	73W17	102837-01 VALVE-GAS (NAT)	1	1	1	1	1	1
370	100597-01 Breaker-Circuit	26W34	100597-01 Breaker-Circuit						
3110	103342-01 Harness-Motor	84W75	103342-01 Harness-Motor	1	1	1	1	1	1
3030	103636-03 HARNESS-WIRING	94W44	103636-03 HARNESS-WIRING			1	1	1	1
3030	608406-03 Harness-Wire	85W95	608406-03 Harness-Wire	1	1				
30	607436-02 Kit -Ignition Control Board	85W79	607436-02 Kit -Ignition Control Board	1	1	1	1	1	1
270	102317-01 SWITCH-INTERLOCK	51W15	102317-01 SWITCH-INTERLOCK	1	1	1	1	1	1
250	102958-01 SIGHT GLASS	73W21	102958-01 SIGHT GLASS	1	1	1	1	1	1
2340	PANEL-UPPER	73W62	PANEL-UPPER	1	1	1	1	1	1
2330	PANEL-LOWER	73W63	PANEL-LOWER	1	1	1	1	1	1
2225	102996-01 Bracket-Burner Mtg-R	69W92	102996-01 Bracket-Burner Mtg-R	1	1	1	1	1	1
2225	102996-02 Bracket-Burner Mtg	69W93	102996-02 Bracket-Burner Mtg-L	1	1	1	1	1	1
2225	ASSY BURNER (10)	69W90	602866-10 Burner Assy (110)	1	1	1	1	1	1
2120	LB-94537 BLOWER HOUSING CUT OFF PLATE	81L92	LB-94537 PLATE-CUTOFF	1	1	1	1	1	1
2110	LB-94726L HOUSING-BLOWER	57M89	LB-94726L HOUSING-BLOWER	1	1	1	1	1	1
210	LB-74940B Flame Sensor Kit (102431-02)	69W43	LB-74940B Flame Sensor Kit	1	1	1	1	1	1
2070	605996-20 Heat Exchanger-OBS	75W27	605996-20 Heat Exchanger	1	1				
2070	605996-29 Heat Exchanger-OBS	75W36	605996-29 Heat Exchanger			1	1		
2070	614580-02 HEAT EXCH ASSY (612983-04)	12Y79	614580-02 HEAT EXCH ASSY (612983-04)	1	1			1	
2070	614580-15 HT EXCH ASSY (612216-44) 1-STG	13X23	614580-15 HT EXCH ASSY (612216-44) 1-STG						1
20	103245-09 SWITCH-PRESS .90	80W67	103245-09 SWITCH-PRESS .90 (0-4500)	1	1				
20	103614-19 SWITCH-PRESSURE .90	93W94	103614-09 SWITCH-PRESSURE .90			1	1		
20	104371-09 Pressure Switch Kit 0.90"	10U94	Honeywell 605187-02 Press Sw Kit 0.90"					1	1
180	42J3201 TRANSFORMER	42J32	42J3201 TRANSFORMER	1	1	1	1	1	1
140	101910-07 ORIFICE-NAT-1/16	69W27	101910-07 ORIFICE-NAT-1/16	1	1	1	1	1	8

95G1UH110CE20				DASH/Revision # with Qty					
Key	Part Name	Part Number	Description	1	2	3	5	6	55
140	102491-04 MANIFOLD -GAS	71W24	102491-04 MANIFOLD-GAS	*1*	*1*	*1*	*1*	*1*	*1*
130	102504-01 Flue-Exh aust	71W26	102504-01 Flue-Exhaust	*1*	*1*	*1*	*1*	*1*	*1*
120	LB-112237B IGNITO R ASSY (100536-03)	70W16	LB-112237B IGNITER	*1*	*1*	*1*	*1*	*1*	*1*
1050	WIRING DIAGRAM LAB EL	537453-01	WIRING DIAGRAM LABEL	*1*	*1*	*1*	*1*	*1*	*1*
10	102857-04 Control-Limit (145F) Main	71W44	102857-04 Control-Limit (145F)	*1*	*1*	*1*	*1*	*1*	*1*
	102906-02 Orifice-LP .034	71W48	102906-02 Orifice-LP .034	*1*	*1*	*1*	*1*	*1*	*1*
	604888-03 ASSY KIT (NAT TO PROPANE CONV)	68W75	604888-03 ASSY KIT (NAT TO PRO PANE CONV)	*1*	*1*	*1*	*1*	*1*	*1*
	605099-04 TRAP ASS Y (GOODY BAG ASSY)	71W17	605099-04 Bag Assy	*1*	*1*				
	605099-07 DRAIN TR AP (GOODY BAG ASSY)	95W17	605099-07 Drain Trap Bag Assy			*1*	*1*	*1*	*1*
	605927-14 Night Se rvice Kit A80,80G1,A95	86W57	Night Service Kit	*1*	*1*	*1*	*1*	*1*	*1*
	607010-01 Drain Tr ap Kit	77W30	607010-01 Drain Trap Kit	*1*	*1*				
	CAP - 1" VINYL	18K92	CAP - 1" VINYL	*1*	*1*				
	LB-110418A Hardwar e Kit (Pkg 10)	97M37	LB-110418A Hardware Kit (Pkg 1 0)	*1*	*1*	*1*	*1*	*1*	*1*
	LB-96015D TUBING K IT-PRESSURE SWITCH	70W93	LB-96015D TUBING KIT-PRESSURE SWITCH			*1*	*1*	*1*	*1*
	R00419B173 PAINT-DUCANE GRAY (BRUSH)	63W14	R00419B173 PAINT-DUCANE GRAY (BRUSH)	*1*	*1*	*1*	*1*	*1*	*1*
	R00419B174 PAINT-DUCANE GRAY (PEN)	63W15	R00419B174 PAINT-DUCANE GRAY (PEN)	*1*	*1*	*1*	*1*	*1*	*1*
	R00419B175 PAINT-DUCANE GRAY (AEROSOL)	63W16	R00419B175 PAINT-DUCANE GRAY (AEROSOL)	*1*	*1*	*1*	*1*	*1*	*1*

95G1UH110CE20				DASH/Revision # with Qty	
Key	Part Name	Part Number	Description	56	57
Category:					
9080	604888-03 ASSY KIT (NAT TO PROPANE CONV)	68W75	604888-03 ASSY KIT (NAT TO PRO PANE CONV)	1	1
90	LB-29333BCW WHEEL-BLOWER	36M22	LB-29333BCW WHEEL	1	1
820	102862-01 Coupling -2"	72W54	102862-01 Coupling-2"		
820	102862-02 Flue Coupling Service Kit	14K09	102862-02 Flue Coupling Service Kit	1	1
721	102809-01 Hose Drain (UH)	71W35	102809-01 Hose Drain (UH)		
721	102809-02 Hose Drain (UH)	71W36	102809-02 Hose Drain (UH)	1	1
721	102809-03 Hose Drain	98W72	102809-03 Hose Drain	1	1
700	614169-01 AIR INLET GASKET ASSY	71W27	102510-01 Collar-Air Inlet	1	1
70	100071-03 SLEEVE	42W05	100071-03 Sleeve	4	4
70	43H8101 GROMMET	43H81	GROMMET	4	4
70	607421-11 X13 1HP Motor - Programmed	81W42	607421-11 X13 1HP Motor - Programmed	1	1
70	ARM-MOTOR MTG	49L97	ARM-MOTOR MTG	4	4
70	MOUNT-MOTOR	32M17	MOUNT-MOTOR	1	1
60	102907-01 Roll Out Switch (210F)	71W49	102907-01 Roll Out Switch (210F)	2	2
53	104007-01 TRANSFORMER POWER CHOKE	10Y66	104007-01 TRANSFORMER POWER CHOKE	1	1
53	42J3201 TRANSFORMER	42J32	42J3201 TRANSFORMER	1	1
53	69H1201 POWER CHOKE	69H12	POWER CHOKE		
500	102788-17 Box-Collector	77W17	102788-17 Box-Collector		
500	102788-31 Box-Collector (See text)	86W22	102788-31 Box-Collector		
500	610261-12 Box-Collector (103370-15)	95W96	610261-15 Box-Collector		
500	610261-37 BOX-COLLECTOR (103370-53)	13H42	610261-37 Cold End Header Box Kit	1	
500	610261-43 BOX-COLLECTOR (103370-69)	13U37	610261-43 BOX-COLLECTOR (103370-69)		1
50	LB-94724AE Assy-Blower (Replacemt-Comb)	93W13	LB-94724AE Assy-Blower (Replacemt-Comb)	1	1
50	LB-94724Y Blower-Comb Air S/A	73W44	LB-94724Y Blower-Comb Air S/A		

95G1UH110CE20				DASH/Revision # with Qty	
Key	Part Name	Part Number	Description	56	57
40	102837-01 VALVE-GAS (NAT)	73W17	102837-01 VALVE-GAS (NAT)	*1*	*1*
370	100597-01 Breaker-Circuit	26W34	100597-01 Breaker-Circuit		
3110	103342-01 Harness-Motor	84W75	103342-01 Harness-Motor	*1*	*1*
3030	103636-03 HARNESS-WIRING	94W44	103636-03 HARNESS-WIRING	*1*	*1*
3030	608406-03 Harness-Wire	85W95	608406-03 Harness-Wire		
30	607436-02 Kit -Ignition Control Board	85W79	607436-02 Kit -Ignition Control Board	*1*	*1*
270	102317-01 SWITCH-INTERLOCK	51W15	102317-01 SWITCH-INTERLOCK	*1*	*1*
250	102958-01 SIGHT GLASS	73W21	102958-01 SIGHT GLASS	*1*	*1*
2340	PANEL-UPPER	73W62	PANEL-UPPER	*1*	*1*
2330	PANEL-LOWER	73W63	PANEL-LOWER	*1*	*1*
2225	102996-01 Bracket-Burner Mtg-R	69W92	102996-01 Bracket-Burner Mtg-R	*1*	*1*
2225	102996-02 Bracket-Burner Mtg	69W93	102996-02 Bracket-Burner Mtg-L	*1*	*1*
2225	ASSY BURNER (10)	69W90	602866-10 Burner Assy (110)	*1*	*1*
2120	LB-94537 BLOWER HOUSING CUT OFF PLATE	81L92	LB-94537 PLATE-CUTOFF	*1*	*1*
2110	LB-94726L HOUSING-BLOWER	57M89	LB-94726L HOUSING-BLOWER	*1*	*1*
210	LB-74940B Flame Sensor Kit (102431-02)	69W43	LB-74940B Flame Sensor Kit	*1*	*1*
2070	605996-20 Heat Exchanger-OBS	75W27	605996-20 Heat Exchanger		
2070	605996-29 Heat Exchanger-OBS	75W36	605996-29 Heat Exchanger		
2070	614580-02 HEAT EXCH ASSY (612983-04)	12Y79	614580-02 HEAT EXCH ASSY (612983-04)	*1*	
2070	614580-15 HT EXCH ASSY (612216-44) 1-STG	13X23	614580-15 HT EXCH ASSY (612216-44) 1-STG		*1*
20	103245-09 SWITCH-PRESS .90	80W67	103245-09 SWITCH-PRESS .90 (0-4500)		
20	103614-19 SWITCH-PRESSURE .90	93W94	103614-09 SWITCH-PRESSURE .90		
20	104371-09 Pressure Switch Kit 0.90"	10U94	Honeywell 605187-02 Press Sw Kit 0.90"	*1*	*1*
180	42J3201 TRANSFORMER	42J32	42J3201 TRANSFORMER	*1*	*1*
140	101910-07 ORIFICE-NAT-1/16	69W27	101910-07 ORIFICE-NAT-1/16	*10*	*10*

95G1UH110CE20				DASH/Revision # with Qty	
Key	Part Name	Part Number	Description	56	57
140	102491-04 MANIFOLD -GAS	71W24	102491-04 MANIFOLD-GAS	*1*	*1*
130	102504-01 Flue-Exh aust	71W26	102504-01 Flue-Exhaust	*1*	*1*
120	LB-112237B IGNITO R ASSY (100536-03)	70W16	LB-112237B IGNITER	*1*	*1*
1050	WIRING DIAGRAM LAB EL	537453-01	WIRING DIAGRAM LABEL	*1*	*1*
10	102857-04 Control-Limit (145F) Main	71W44	102857-04 Control-Limit (145F)	*1*	*1*
	102906-02 Orifice-LP .034	71W48	102906-02 Orifice-LP .034	*1*	*1*
	604888-03 ASSY KIT (NAT TO PROPANE CONV)	68W75	604888-03 ASSY KIT (NAT TO PRO PANE CONV)	*1*	*1*
	605099-04 TRAP ASS Y (GOODY BAG ASSY)	71W17	605099-04 Bag Assy		
	605099-07 DRAIN TR AP (GOODY BAG ASSY)	95W17	605099-07 Drain Trap Bag Assy	*1*	*1*
	605927-14 Night Se rvice Kit A80,80G1,A95	86W57	Night Service Kit	*1*	*1*
	607010-01 Drain Tr ap Kit	77W30	607010-01 Drain Trap Kit		
	CAP - 1" VINYL	18K92	CAP - 1" VINYL		
	LB-110418A Hardwar e Kit (Pkg 10)	97M37	LB-110418A Hardware Kit (Pkg 1 0)	*1*	*1*
	LB-96015D TUBING K IT-PRESSURE SWITCH	70W93	LB-96015D TUBING KIT-PRESSURE SWITCH	*1*	*1*
	R00419B173 PAINT-DUCANE GRAY (BRUSH)	63W14	R00419B173 PAINT-DUCANE GRAY (BRUSH)	*1*	*1*
	R00419B174 PAINT-DUCANE GRAY (PEN)	63W15	R00419B174 PAINT-DUCANE GRAY (PEN)		
	R00419B175 PAINT-DUCANE GRAY (AEROSOL)	63W16	R00419B175 PAINT-DUCANE GRAY (AEROSOL)	*1*	*1*

NOTE