A96DS2V070B16S				DASH/Revision # with Qty		
Key	Part Name	Part Number	Description	1	2	3
Category:CABINET PARTS						
250	MP 100008-01 SIGHT GLASS	49L04	100008-01 SIGHT GLASS	*1*	*1*	*1*
2340	PANEL-UPPER	73W62	PANEL-UPPER	*1*	*1*	*1*
2330	PANEL-LOWER	73W63	PANEL-LOWER	*1*	*1*	*1*
110	103013-02 Panel-Filler Door Trim	74W14	103013-02 Panel-Filler Door Trim	*1*	*1*	*1*
110	LB-110418B Thumb Screw Bag Assy (Pkg 10)	78W50	LB-110418B Thumb Screw Bag Assy (Pkg 10)	*1*	*1*	*1*
	605099-07 DRAIN TRAP (GOODY BAG ASSY)	95W17	605099-07 Drain Trap Bag Assy	*1*	*1*	*1*
	ARMS PLATINUM GRAY PAINT PEN (TOP & CAB)	R00419B171	ARMS PLATINUM GRAY PAINT PEN (TOP & CAB)	*1*	*1*	*1*
	ARMSTRONG SLATE GRAY PAINT PEN (DOORS)	R00419B169	ARMSTRONG SLATE GRAY PAINT PEN (DOORS)	*1*	*1*	*1*
	ARMSTRONG TEXT PLATINUM GRAY (TOP & CAB)	R00419B165	ARMSTRONG TEXT PLATINUM GRAY (TOP & CAB)	*1*	*1*	*1*
	ARMSTRONG TEXTURED SLATE GRAY (DOORS)	R00419B164	ARMSTRONG TEXTURED SLATE GRAY (DOORS)	*1*	*1*	*1*
	LB-110418A Hardware Kit (Pkg 10)	97M37	LB-110418A Hardware Kit (Pkg 10)	*1*	*1*	*1*
Category:HEATING PARTS						
9080	604888-08 Nat/LP Conv KIt A96/95G2	78W94	604888-08 Nat/LP Conv KIt A95/A95G	*1*		*1*
9080	604888-15 CONV KIT	11K48	604888-15 CONV KIT		*1*	
820	102862-01 Coupling-2"	72W54	102862-01 Coupling-2"	*1*	*1*	*1*
720	102865-01 Hose Drain (DF)	71W46	102865-01 Hose Drain (DF)	*1*	*1*	*1*
700	102859-01 Collar-Air Inlet (DF)	72W51	102859-01 Collar-Air Inlet (DF)	*1*	*1*	*1*
60	102907-01 Roll Out Switch (210F)	71W49	102907-01 Roll Out Switch (210F)	*2*	*2*	*2*
500	610261-10 Box-Collector - OBS	95W94	610261-10 Box-Collector	*1*		
500	610261-33 BOX-COLLECTOR (103370-47)	11U58	610261-33 Cold End Header Box Kit		*1*	*1*
40	103181-02 VALVE-GAS (2 STG NAT)	83W12	103181-02 VALVE-GAS (2 STG NAT)	*1*	*1*	*1*
40	609627-01 Kit-Gas Valve Barbed Fitting	92W78	609627-01 Kit-Gas Valve Barbed Fitting	*1*	*1*	*1*
2225	102996-01 Bracket-Burner Mtg-R	69W92	102996-01 Bracket-Burner Mtg-R	*1*	*1*	*1*
2225	102996-02 Bracket-Burner Mtg	69W93	102996-02 Bracket-Burner Mtg-L	*1*	*1*	*1*

A96DS2V070B16S				DASH/Revision # with Qty		
Key	Part Name	Part Number	Description	1	2	3
2225	ASSY BURNER (6)	69W88	ASSY BURNER (6)	*1*	*1*	*1*
210	LB-74940B Flame Se nsor Kit (102431-02)	69W43	LB-74940B Flame Sensor Kit	*1*	*1*	*1*
2070	605996-61 HEAT EXC H ASSY (612225-12)-OBS	98W42	605996-61 HEAT EXCHANGER ASSY	*1*		
2070	614580-33 HEAT EXC H ASSY (612224-06)	13X41	614580-33 HEAT EXCH ASSY (6122 24-06)		*1*	*1*
20	104549-01 Pressure Switch 2-STG-.90/-.45	14A43	104549-01 Pressure Switch 2-ST G-.90/-.45	*1*	*1*	*1*
140	101910-07 ORIFICE-NAT-1/16	69W27	101910-07 ORIFICE-NAT-1/16	*1*	*6*	*6*
140	102838-02 MANIFOLD -GAS	71W38	102838-02 MANIFOLD-GAS	*1*	*1*	*1*
13	102858-01 ELBOW - 2" Drain	71W45	102858-01 ELBOW - 2" Drain	*1*		
13	102858-02 ELBOW - 2" Drain	10M22	102858-02 ELBOW - 2" Drain		*1*	*1*
120	LB-112237B IGNITO R ASSY (100536-03)	70W16	LB-112237B IGNITER	*1*	*1*	*1*
10	102857-06 Control-Limit (155F)	73W19	102857-06 Control-Limit (155F)	*1*	*1*	*1*
	102906-02 Orifice-LP .034	71W48	102906-02 Orifice-LP .034	*1*	*1*	*1*
	605927-17 NIGHT SE RVICE KIT-A96US2V/DS2V	89W53	605927-17 NIGHT SERVICE KIT-A9 6US2V/DS2V	*1*	*1*	*1*
Category:BLOWER PARTS						
90	LB-29333BCW WHEEL-BLOWER	36M22	LB-29333BCW WHEEL	*1*	*1*	*1*
70	100071-03 SLEEVE	42W05	100071-03 Sleeve	*4*	*4*	*4*
70	101564-03 MTR 3/4H P VAR SPD 120/240/60/1	42W47	101564-03 MTR 3/4HP VAR SPD 12 0/240/60/1			*1*
70	43H8101 GROMMET	43H81	43H8101 GROMMET	*4*	*4*	*4*
70	606007-02 3.0 ECM 3/4 HP MOTOR ONLY	73W02	606007-02 3.0 ECM 3/4 HP MOTOR ONLY	*1*	*1*	
70	606008-05 3.0 ECM ¾ HP MODULE ONLY	84W86	606008-05 3.0 ECM ¾ HP MODULE ONLY	*1*	*1*	*1*
70	ARM-MOTOR MTG	49L97	ARM-MOTOR MTG	*4*	*4*	*4*
70	MOUNT-MOTOR	32M17	MOUNT-MOTOR	*1*	*1*	*1*
50	LB-94724AC Blower-Comb Air (103274-03)	81W45	LB-94724AC Blower-Comb Air S/A	*1*	*1*	*1*
3110	LB-100797 HARN-WIR E	27M25	LB-100797 HARN-WIRE	*1*	*1*	*1*
3030	606360-03 Harness -Wiring	83W87	606360-03 Harness-Wiring	*1*	*1*	*1*

A96DS2V070B16S				DASH/Revision # with Qty		
Key	Part Name	Part Number	Description	1	2	3
3020	101551-05 HARNESS-MOTOR	60W37	101551-05 HARNESS-MOTOR	*1*	*1*	*1*
30	607308-13 KIT-IGN CNTRL (103131-05)	14C94	607308-13 KIT-IGNITION CONTROL			*1*
30	Kit-Ignition Contr ol Board	87W77	607308-06 Kit-Ignition Control	*1*	*1*	
270	102317-01 SWITCH-I NTERLOCK	51W15	102317-01 SWITCH-INTERLOCK	*1*	*1*	*1*
2120	LB-94537 BLOWER HO USING CUT OFF PLATE	81L92	LB-94537 PLATE-CUTOFF	*1*	*1*	*1*
2110	LB-94726L HOUSING-BLOWER	57M89	LB-94726L HOUSING-BLOWER	*1*	*1*	*1*
180	42J3201 TRANSFORME R	42J32	42J3201 TRANSFORMER	*1*	*1*	*1*
	100597-01 Breaker-Circuit	26W34	100597-01 Breaker-Circuit	*1*	*1*	*1*
	104007-01 TRANSFOR MER POWER CHOKE	10Y66	104007-01 TRANSFORMER POWER CH OKE		*1*	*1*
	69H1201 POWER CHOK E	69H12	69H1201 POWER CHOKE	*1*		
Category:UNIT WIRING DIAGRAM						
1050	WIRING DIAGRAM LAB EL	537751-01	WIRING DIAGRAM LABEL	*1*	*1*	*1*

NOTE